

System recommendation Plasticoate Preventive caring instructions

Preventive care instructions

for mineralized roll roofing in good condition (no cracks, leaks)

1. Clean the roof surface thoroughly. If necessary, strengthen weak points like places where there were construction items inserted with Plasti Cement and Poly Star.
2. Coating with one of the following protection-covering:
 - a) Plasticoate Fibered Aluminum Roof-Coating
(0,3 kg/m²)

or

in case of an inclination-free or an absolutely even roof (a so called zero-roof)
 - b) coating with Plasticoate Roof-Coating
(1,2 kg/m²)

or
 - c) coating with Plasticoate Roof-Coating PC 1,5 kg/m², spread with slate-grits into the wet roof coating (2 till 3 kg/m²)